

RCC 320 MK2 Expansion Grille Kit [RCC640-MK2-PCG]

Install Guide

Overview

The RCC 320 MK2 Expansion Grille Kit provides all of the necessary hardware to create an RCC640-type subwoofer by coupling two RCC 320 MK2 preconstruction subwoofers (RCC320-MK2-PC, sold separately).

The optimum orientation is vertical installation with placement between stud bays.

Box Contents

- (1) RCC640-MK2-PC Perforated Grille (071-1297-xx)
- (2) 3mm Connecting Plates (071-1303-xx)
- (1) Install Guide (this document)

Installation

1. Align the two RCC320 subwoofers.
2. Using M6x8mm screws (included with the RCC 320 MK2 Subs), attach the connecting plates to RCC 320 MK2 preconstruction subwoofers.
3. Add the mounting brackets included with the RCC MK2 subwoofers.
4. Attach the assembled subwoofer unit to stud bays using the appropriate screws for the specific installation (not included).

NOTE: See the RCC MK2 Series Install Guide 009-1947-xx for additional information including wiring to the RCC1000-SA digital amplifier.

